

Overview

Thank you for purchasing our product this time. This manual provides complete information on how to configure and use PRICOM.

This manual is edited commonly for several products and there are some parts not applied for your use.

Latest Information on PRICOM

Following services are available via our web site. You can get more information at <http://www.silex.jp/>

- Latest firmware download
- Latest configuration utility download
- Latest manual download
- Supported printers information
- FAQ information
- New products information
- Others

Installation

This chapter explains how to install PRICOM. Follow the instructions corresponding to the network environment in use to realize network printing. Refer to the parts you need to install PRICOM.



-The following instruction may vary depending on your network environment.



-Make sure to install printer driver to your personal computer before you start using PRICOM.

Configuration Utility



-The below contains the explanation for PRICOM configuration. Choose an option corresponding to your network environment.

Configuration Utility	Quick Setup	Initial installation of PRICOM (Recommended)	Chapter 3,4
	Advanced Setup	Advanced configuration for Administrators	Chapter 8
	JC-Print2002	Install Printing Software and Pop-up Printer Monitor	Chapter 3,4

Installation and Configuration (For Administrators)

This contains explanation for PRICOM installation and configuration.

STEP1	Connect PRICOM to printer	Chapter 1
STEP2	Use PRICOM in Windows 95/98/Me	Chapter 3
	Use PRICOM in Windows NT 4.0, Windows 2000, Windows XP	Chapter 4
	Use PRICOM in UNIX/Linux	Chapter 5
	Use PRICOM in Netware	Chapter 6
STEP3	Use PRICOM in Macintosh	Chapter 7

Configuration (For Clients)

This contains explanation for PRICOM configuration.

STEP1 Configuration	Use PRICOM in Windows 95/98/ME	Chapter 3
	Use PRICOM in Windows NT 4.0, Windows 2000, Windows XP	Chapter 4
	Use PRICOM in NetWare	Chapter 6
	Use PRICOM in Macintosh	Chapter 7
STEP2 Print	Test Print (Diagnostic/Configuration report) and verify the configuration	Chapter 1

Advanced Configuration for Administrators

This contains explanation for PRICOM advanced configuration utility, AdminManager.

AdminManager	Configure PRICOM by AdminManager	Chapter 8
	Configure PRICOM by Web browser	
	Configure PRICOM by TELNET	