

**PRICOM C-6200U**
**Supported protocols**
**TCP/IP (Support IPP), IPX Peer to Peer**

The printer model names in this compatible printer list may be called differently in your geographic location. If you do not find your printer model number in the list, please contact (support@silexamerica.com or support@silexeurope.de) for further compatibility information.

| Printer model | Note                  |
|---------------|-----------------------|
| LBP3800       | *1                    |
| LBP3700       | *1                    |
| LBP3200       | *3, *5                |
| LBP-2810      | *1                    |
| LBP-2710      | *1                    |
| LBP-2410      | *3, *4, *5            |
| LBP-2360      | *1                    |
| LBP-2300      | *1                    |
| LBP-2050      | *1                    |
| LBP-1910      | *1                    |
| LBP-1810      | *1                    |
| LBP-1710      | *1                    |
| LBP-1610      | *1                    |
| LBP-1510      | *1                    |
| LBP-1310      | *1                    |
| LBP-1210      | *9                    |
| LBP-1120      | *3, *9                |
| LBP-1110SE    | *9                    |
| LBP-1110      | *9, *13               |
| LBP-810       | *9, *13               |
| LBP-350       | *1                    |
| MF5650        | *2, *3                |
| CX350         | *2, *3, *10, *11, *12 |
| MP950         | *2, *3, *6            |
| MP800         | *2, *3, *6            |
| MP780         | *2, *3, *6, *8, *14   |
| MP760         | *2, *3, *6, *8, *14   |
| MP750         | *2, *3, *6, *14       |

|               |                        |
|---------------|------------------------|
| MP740         | *2, *3, *6, *8         |
| MP730         | *2, *3, *4, *6, *7, *8 |
| MP710         | *2, *3, *6             |
| MP700         | *2, *3, *4, *6, *7     |
| MP500         | *2, *3, *6             |
| MP450         | *2, *3, *6             |
| MP390         | *2, *3, *6, *8         |
| MP370         | *2, *3, *6             |
| MP360         | *2, *3, *6             |
| MP170         | *2, *3, *6             |
| MP150         | *2, *3                 |
| iP8500        | *2, *3                 |
| iP6600D       | *2, *3                 |
| iP6220D       | *2, *3                 |
| iP6210D       | *2, *3                 |
| iP6000D       | *2, *3                 |
| iP5200        | *2, *3                 |
| iP5000        | *2, *3                 |
| iP4200        | *2, *3                 |
| iP4000        | *2, *3                 |
| iP3000        | *2, *3                 |
| iP2200        | *2, *3                 |
| iP2000        | *2, *3                 |
| iP1600        | *2, *3                 |
| iP1500        | *2, *3                 |
| iP90          | *2, *3                 |
| i9950         | *2, *3                 |
| i9100         | *2, *3                 |
| i6500         | *2                     |
| i6100         | *2                     |
| i990          | *2, *3                 |
| i965          | *2, *3                 |
| i960          | *2, *3                 |
| i950          | *2, *3                 |
| i900D / i905D | *2, *3                 |
| PIXUS 865R    | *2, *3                 |
| i860          | *2                     |
| i850          | *2                     |
| i560          | *2                     |
| i550          | *2                     |
| i475D         | *2, *3                 |
| i470D         | *2, *3                 |
| i455          | *2, *3                 |
| i450          | *2, *3                 |
| i320          | *2, *3                 |
| i80           | *2, *3, *10            |

|                   |        |
|-------------------|--------|
| <b>i70</b>        | *2, *3 |
| <b>S9000</b>      | *2, *3 |
| <b>S6300</b>      | *2     |
| <b>S4500</b>      | *2     |
| <b>S900</b>       | *2, *3 |
| <b>S830D</b>      | *2, *3 |
| <b>S820D</b>      | *2, *3 |
| <b>S820</b>       | *2     |
| <b>S800</b>       | *2     |
| <b>S750</b>       | *2     |
| <b>S630</b>       | *2     |
| <b>S600</b>       | *2     |
| <b>S530D</b>      | *2, *3 |
| <b>S520</b>       | *2     |
| <b>S500</b>       | *2     |
| <b>S450</b>       | *2     |
| <b>S400</b>       | *2     |
| <b>S330</b>       | *2, *3 |
| <b>S300</b>       | *2, *3 |
| <b>S200</b>       | *2, *3 |
| <b>S100</b>       | *2, *3 |
| <b>BJ F930</b>    | *2, *3 |
| <b>BJ F860</b>    | *2     |
| <b>BJC-8200</b>   | *2     |
| <b>BJC-6500</b>   | *2     |
| <b>BJC-6200</b>   | *2     |
| <b>BJC-6100</b>   | *2     |
| <b>BJC-3000</b>   | *2     |
| <b>BJC-2100</b>   | *2, *3 |
| <b>BJC-2100SP</b> | *2     |
| <b>BJC-85</b>     | *2     |
| <b>BJC-55</b>     | *2, *3 |

\*1 This model does not support the printer status monitor.

\*2 This model does not support Windows Server 2003, because the printer driver is not available.

\*3 This model does not support Windows 95, WindowsNT4.0, because the printer driver is not available.

\*4 Please use PRICOM-Print CX Version 3.1.0 or later.

\*5 Please use firmware version 1.2.0 or later.

\*6 To scan via the network, use the "PRICOM USB Utility". (Windows 2000/XP only)

\*7 Please use firmware version 1.1.0 or later.

\*8 This model does not support PC fax function.

\*9 Please use PRICOM-Print CX Version 3.0.0 or later.

\*10 Please use firmware version 1.4.0 or later.

\*11 Please use PRICOM-Print CX Version 3.2.0 or later.

\*12 This model does not support Windows 98, because the printer driver is not available.

\*13 For Canon LBP-810 / LBP-1210 users.

The latest printer driver must be used as follows.

LBP-810 : R1.04 or later version

LBP-1210 : R1.01 or later version

We recommend you to visit the following web site to obtain the latest printer driver.

Canon web site: <http://www.canonusa.com>

\*14 Please use C-6200U firmware version 1.5.0 or later and C-6200U+ firmware version 2.1.0 or later.